

**BMC**  
SWITZERLAND 



**Trailsync**  
Dust Wiper Cleaning

# Trailsync

## Dust Wiper Cleaning

### Contents

1.	Tools necessary	3
2.	General Note	4
3.	Step by Step instructions	5

# 1. Tools necessary:

**Work Stand:**



**Clean Rags:**



**Allen Keys:**



**5 Minutes**



**Grease:**



## 2. General Note

We recommend:


- fully cleaning the dust wiper seal at 50 hours intervals for the best functionality.
- a full seatpost service at every 200 hours of use, or approx. every 2 years (depending on rider mileage).

The Trailsync seatpost service must be performed by authorized BMC retailers.

### 3. Step by Step instructions



- 1 Unscrew the M5 screw of the seatpost head.
- 2 Remove the seatpost head from the Trailsync seatpost; it's not necessary to remove the saddle.



- 3 Pull the seal head and remove it from the tube.
- 4 Thoroughly clean all the parts.



5 Grease the seal head.

6 Re-assemble the seal head.

**Notice:**  
*A clicking sound can be heard when the dust wiper is correctly locked into position.*



7 Reassemble the Saddle head.

8 Align the saddle and tighten the seatpost head with the recommended torque.

**Notice:**  
*Recommended Torque is 6 Nm.*